






## FITMENT INSTRUCTIONS



TOYOTA LAND CRUISER DOUBLE-&amp;-SINGLE CAB

XPEDITION &amp; LX

## FITMENT KIT CONTENTS

DESCRIPTION	QUANTITY	ILLUSTRATION
• M8 x 25 Bolt	4	
• M8 Nylock Nut	4	
• M8 Flat Washer	4	
• M8 Body Washer	4	
• M8 Spring Washer	4	

## REQUIRED TOOLS

DESCRIPTION	ILLUSTRATION
• 13mm Spanner	
• 13mm Socket Wrench (Optional)	
• Philips Screwdriver	
• Drill	
• 9mm Drill bit	

## INSTALLATION TIME &amp; CARE INSTRUCTIONS

Approx. 45 Minutes (Excluding the removal of any accessories from load bin)

- ✓ Before installation, ensure that your hands and workwear are clean from oil, grime & dirt.
- ✓ Ensure that the correct tools and PPE are used whilst installing the canopy. Clean the rear cab window before fitting the canopy.
- ✓ Torque all M8 fasteners to approx. 28Nm.

## FITMENT STEPS

## STEP 1

- ✓ Unpack all components and hardware from packaging: ensure that everything is accounted for as indicated above.

## STEP 2

- ✓ Remove any cab guards, roll bar, tonneau cover, sports bar etc. from vehicle.



REMOVE THE SCREW  
WITH A PHILIPS  
SCREWDRIVER.

REMOVE THE SCREW  
WITH A PHILIPS  
SCREWDRIVER.

### STEP 3

- ✓ Prior to loading the canopy for fitment, ensure that the rear cab window of the vehicle is clean.
- ✓ Fit the canopy to the loading bin, align & space evenly.
- ✓ Ensure that the canopy is on its maximum position to the front. This can be verified by the cavity in the front panel, which will bottom out against the remainder of the roll bar section.
- ✓ Identify the bolt position in the front & rear section of the canopy as illustrated. Ensure that these marks will be more or less in the middle of the load box edge.
- ✓ Drill a Ø9 hole into the canopy through the load box (Ø5mm pilot hole recommended for accuracy) **NOTE: XP models will have pre-drilled fitment holes. Use the pre-drilled hole positions form marking on the load box.**

**REAR CORNER**



**FRONT CORNER**



### STEP 4

- ✓ Secure the canopy to the load box edges using the bolts supplied, tighten the bolts to secure the two surfaces firmly.

### STEP 5

- ✓ Trim sealing rubber on tailgate with knife or scissors.
- ✓ Check again for alignment of canopy on sides of loading bin.
- ✓ Check all bolts one final time.
- ✓ Enjoy your NEW Rhinoman all Aluminum Canopy.



## WARRANTY SERVICE &amp; CARE GUIDE

- ✓ All Rhinoman products carry a comprehensive 2-year factory warranty.
- ✓ **PLEASE NOTE:** Your canopy will only be covered under warranty if it has been fitted by an approved Rhinoman fitment center or agent.
- ✓ Please do inspect the fasteners on the fitment brackets every once in a while, to ensure that all bolts are still tight and properly secured.

SHOULD YOU HAVE ANY ENQUIRIES ABOUT THE FITMENT, FEEL FREE TO CONTACT US



010 010 0060



SALES@RHINOMAN.CO.ZA



RHINOMAN.CO.ZA